

M3 MASK LENS INSTRUCTIONS



DISASSEMBLY PROCEDURE

- 1. Using the supplied Lens Removal Tool supplied with the Optical Lens Kit, lift the one of the lower corner tabs of the retaining frame (Fig. 1).
- 2. Using the Lens Removal Tool, carefully release the remaining retaining tabs (*Fig. 2*).
- 3. Repeat steps 1 and 2 on the other lens.
- 4. Release the locking tab on the backside of the main frame, behind the Hollis logo (*Fig. 3*). Then lift the retainer frame off of the mask.
- 5. Press the lenses out of the mask skirting.



Fig. 1



Fig. 2



Fig. 3

SUPPORT: TOLL-FREE 888-383-DIVE • FAX 510-729-5115 • E-MAIL INFO@HOLLISGEAR.COM



REASSEMBLY PROCEDURE

- 1. Align and press the lenses into the mask skirting, as shown (Fig.
- 4). Ensure they seat smoothly.
 - Note: When looking at the front of the mask, the printing on the lenses should read left to right across the top.
- 2. Align the locking tab, and install the retaining frame at a 45° angle, as shown (Fig. 5).
- 3. Secure the center section of the retaining frame by down and upwards, as shown (*Fig. 6*).



Fig. 4



Fig. 5



Fig. 6



- 4. Following along the edge of one lens, press the retaining frame into place (*Fig. 7*). Ensure all tabs are secured into the main frame.
- 5. Repeat step 4 for the other lens.
- 6. Inspect the assembly to ensure all parts are fitted securely and smoothly (Fig. 8).



Fig. 7



Fig. 8