

MASK DIVE COMPUTER

OPERATING MANUAL

Addendum

SET FO2:

Information that follows amends the FO2 Set procedure presented in the manual provided for Masks with integrated Dive Computers.

FO2, which previously had a Nitrox set range of 21 to 50%, can now be set for Nitrox having up to 99% O2 and for 100% O2.

Set operations remain the same as described in the manual with the S button push and hold scroll now stopping momentarily at 32, then at 50, then at 80, then 100* before returning to 21%.

** Due to the limitation of display digits, 100% is displayed as 00.*