



## *ProEar 2000™ Mask*

### **INSTRUCTIONS**

#### **Function**

A common mask provides an air space in front of the eyes to eliminate distorted vision. ProEar 2000 also keeps the ears dry and simplifies equalization of pressures by channeling air from the mask through flexible tubes to each of the ear cups.

#### **Preparation**

Prior to using the mask for the first time, thoroughly clean both sides of the lens with a nonabrasive liquid detergent, or toothpaste, to remove any residue, then rinse with fresh water.

Adjust the side straps and head strap so the mask is comfortably and firmly in position on your face without being too tight or restrictive and the ear cups are comfortably positioned to cover your ears.

## Use

To prevent fogging during use, rub a 'no fog' solution, or saliva, on the inner surface of the lens while it is still dry, then rinse with water.

R1

Place the mask on your face and pull the strap over the top of your head.

To clear water that enters the mask, tilt your head slightly back and exhale gently into the mask while pressing the top portion with your fingers. Water will be forced out the bottom edge.

To eliminate mask squeeze and simplify equalization of your ears caused by the higher pressures, exhale slowly into the mask through your nose as you descend. Equalize your ears as necessary by pinching your nose closed with your thumb and finger and blowing gently while holding your mouth closed.

## Care and Maintenance

At the end of each dive day, thoroughly rinse your mask, ear cups, and flex tubes with gently running fresh water and towel dry. **DO NOT attempt to remove the flex tubes.**

DO NOT allow the clear silicone components to come in contact with items that are black rubber. They will discolor.

R1

**Avoid prolonged exposure to direct sunlight or excessive heat.**

Ensure that the ProEar 2000 is completely dry before storing. Store in a cool, dry location.