# **(-)OLLIS** R ELITE 2 HARNESS

# USER GUIDE



# NOTICES

# LIMITED WARRANTY

For details, refer to the Product Warranty section on the Hollis web site: www.HollisGear.com

# **COPYRIGHT NOTICE**

This operating manual is copyrighted, all rights are reserved. It may not, in whole or in part, be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine readable form without prior consent in writing from Hollis.

> Elite 2 Harness User Guide, Doc. No. 12-4176 © Hollis, 2014 San Leandro, CA USA 94577 (510)729-5110 www.hollisgear.com e-mail: info@hollisgear.com

#### TRADEMARK, TRADE NAME, AND SERVICE MARK NOTICE

HOLLIS, the HOLLIS logo type, and Elite 2 are registered and unregistered trade-marks, trade names, and service marks of HOLLIS. All rights are reserved.



WAIST/LOWER SHOULDER ASSEMBLY

## **ELITE 2 HARNESS PARTS**



UPPER SHOULDER ASSEMBLY



CROTCH STRAP ASSEMBLY

# ASSEMBLY

# WAIST STRAP

The Elite 2 comes with two lengths of 2 in (5.1 cm) nylon webbing straps. Use the shorter of the two to construct the waist strap assembly. Working from the backside of the backplate, run the 2 in (5.1 cm) nylon webbing through the waist slots on the backplate as shown (*Fig. 1, 2*). Next run the shoulder strap plate through the waist strap as shown (*Fig. 3*). Repeat on the other side. Install the belt slide and D-ring one on each side as shown (*Fig. 4, 5*).



Fig. 1

Fig. 2

Fig. 3



Fig. 4



Fig. 5

## UPPER SHOULDER STRAP

With the longer of the two lengths of webbing provided with the Elite 2 weave the strap as follows. From the back side of your backplate insert the webbing as shown (*Fig. 6, 7, 8*).



Fig. 6







Fig. 8

(•)ollis.

On the left side weave the shoulder pad with the 2 in (5.1 cm) webbing panel at the top as shown in (Fig. 9, 10). Next weave through a belt slide and then through the panel on the epaulette (*Fig. 11*).



Fig. 9

Fig. 10

Fig. 11

Weave a belt slide and bent D-Ring as shown (*Fig. 12*). Then weave under the 1 in (2.5 cm) panel (*Fig. 13*). Next weave another belt slide and bent D-Ring onto the webbing (*Fig. 14, 15*).



Fig. 12



Fig. 13




Fig. 14



Fig. 15

Take one of the two D-Rings with the webbing leads and clips attached and weave the webbing as shown (*Fig.* 16). Make sure the larger female clip faces down. The sternum strap (lead with the smaller clip) should face inward toward the center chest (*Fig.* 16, 18). Weave the webbing back through the 3 belt slides (*Fig.* 17). The left side shoulder strap should now look like the photo (*Fig.* 18).



Repeat the steps to install the shoulder strap on the right hand side.

### **CROTCH STRAP**

Take the side of the crotch strap that is not looped; secure a D-Ring with a belt slide leaving about 8 in (20.3 cm) of webbing between the slide and the end of the webbing. Then weave webbing through the backplate from the back side (*Fig. 19*). Use the larger slot at the center of the backplate's bottom and weave the webbing back through the belt slide (*Fig. 20*). This is where adjustment to the crotch strap will be made. The looped end will thread onto the waist strap. When adjusted properly the D-ring should be spaced approximately one hand width from the backplate, facing the backside, and secured with a belt slide (*Fig. 21*).



Fig. 19




Fig. 20



Fig. 21

#### WAIST BUCKLE

Insert the waist buckle on the left side of the waist webbing. See pictures for recommended buckle weave. Weave (*Fig. 22*). When at the desired length pull the remaining webbing through the first slot and tighten (*Fig. 23*).



# **!** NOTE: Excess waist strap material may trimmed. To prevent fraying, use a lighter to burn the edge of trimmed webbing.

**POST DIVE CARE** 

Rinse with fresh water and allow to air dry.